

How to replace the front brake pads of disc brake on Honda CR-V 2

Carry out replacement in the following order:

ⓘ

Perform the replacement of brake pads in complete set for each axis. This provides effective braking.

Do not wash the brake elements with gasoline, diesel fuel or gasoline-based solvents.

Observe the safety procedures! when brake pads work, brake dust is formed. Therefore, do not use compressed air and do not inhale dust when cleaning the brake pads.

1

Tighten the parking brake lever.

2

Place wedge blocks under the rear wheels.

3

Loosen the wheel mounting bolts.

4

Raise the front of the car and secure on supports.

5


Remove the front wheels.

6.1



Unscrew the brake caliper fastening

6.2



6.3



7



Remove the brake caliper.

AutoDoc recommends:

Do not press the brake pedal after removing the brake pads. This will lead to the piston drop out of the brake cylinder, brake fluid leakage and the system depressurization.




Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.




How to replace the front brake pads of disc brake on Honda CR-V 2

8.1




8.2



Remove the brake pads.

8.3



9


Clean the brake caliper bracket from dirt and dust.

10



With the help of a special tool push in the brake caliper piston to a stop.

11.1




Install new brake pads




How to replace the front brake pads of disc brake on Honda CR-V 2

11.2


11.3




12.1




12.2





Install the brake caliper and fix it.

12.3



13

Install the wheel.

14

Lower the car and working in a cross order, tighten the wheel bolts.



AutoDoc recommends:

Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unneccessary and sharp braking to a stop.

Check the brake fluid level in the expansion tank and refill if necessary.



Video tutorials

Watch our detailed video guides about your Honda CR-V 2 repair on our youtube channel. Watch video guides.



AutoDoc online

Highest quality brake pads for your car Honda CR-V 2 are available on AutoDoc. Go to the website.

We hope that this information have been useful for you!




How to replace the front brake pads of disc brake on Honda CR-V 2

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

QUALITY AUTO PARTS



HONDA



BRAKE PADS



HONDA CR-V 2



BRAKE PADS FOR HONDA



BRAKE PADS FOR HONDA CR-V 2



Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement works. AutoDoc shall not be liable for any loss, injury, damage of property, acquired in the repair or replacement process due to incorrect usage or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for informative purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

AUTODOC IN SOCIAL MEDIA